

CHRONOS QUICK START

- ON** Press red button.
- OFF** Hold red button and press a player button 5 times.
- START** Press either player button.
- PAUSE** If clock is running, press red button to pause.
- RESUME** If clock is paused, press a player button to resume.
- RESET** Press red button 4 times, or 5 times if clock is running.
In quick reset modes, press 1 or 2 times.

TURN ON MODES

- 1-4** Press red button. Then press red button to cycle through modes.
- 5-8** Press left button and red button. Then press red button to toggle 5-6, 7-8. Use a player button to choose mode.
- 9-12** Press right button and red button. Then press red button to toggle 9-10, 11-12. Use a player button to choose mode.
- ALL** Press left and right buttons and press red button. Then press red button to cycle through modes. Use long press to move back. Use a player button to choose mode.
- NEW** Reset clock and press red button 3 times to return to mode selection.

CUSTOMIZE A MODE

Choose an existing user mode or turn on all modes and choose mode closest to the one you want.

Long press red button to start customizing.

Use red button to move among timer digits and options.

Use player buttons to set timer digits and options.

Use "Copy to 0" for a temporary mode.

Use "Copy to ..." and choose number from 1 to 12 to save a mode.

Long press red button to end customizing.